




DEVICE ADDRESS DECODER




CONTROL BUS INPUTS




SELECT COMMAND DECODER



INPUT COMMAND DECODER



SENSE ENCODER



OUTPUT COMMAND DECODER

(C4) OUT 9 39 8 TLD (C12, B1Q)

(C1) FCI 11 39 8 862

(C4) PLSE 10 862

OPF 7

7408

836

FC 7 (B1)

7408

836

ENBL (B2, C2A7)

7408

836

(C3) INZX

846

(A2) DB00

7475

2

Q

EN (C15)

7475

2

Q

EN (C11)

7475

2

Q

EN (A6)

7475

2

Q

EN (A10)

7475

1


Q


EN (A10)

7475


INTERRUPT REQUEST

FLIP-FLOPS






TRANSMIT SHIFT GENERATOR




TRANSMIT

CONTROL IN




TRANSMIT SHEET COUNT









(C12) SEND -

* TEST
SEE TABULATION BLOCK (THIS SH

P/O TRANSMIT CONTROL



52227-XX



* TEST,
SEE TABULATION BLOCK (SHT.